

SUBSTATION		Attachment 10
		ERS.
tics LV Type 4-5 Signal		BLAD 1 FORTS.BLAD 2
· · ·		
	LV voltage measurement	
· 	   T11 LV current measurement	
		rent measurement
: 		
· · ·		
 	T12 LV current measurement	
l i		
	T11 tempe	rature
	T12 tempe	rature
:		
 	Spare ter	perature
	Room temj	perature
1		

