NOT	ÄNDRING	INFÖRD	SIGN

EXAMPLE SINGLE-LINE DIAGRAM Low voltage switchgear LV Type 7

|--|

KJS HRo KJS

KONSTR. KOLL. SKALA


SWITCHGEAR

2023–10–02 Single-line diagram

SECONDARY SUBSTATION LV Type 7

Attachment 7

ERS. BLAD



٧ Three phase voltage measurement connected to the RTU

| A | Current measurement connected to the RTU

man. Maneuver from RTU

pos. Double point position of Beraker/Load disconnector

sign. Signal/Alarm